

Decorative Hardware Poles for Mounting Drapery Panels & Valances

- Measure the window/wall area you want to cover with drapery panels/pole mounted valances. We recommend mounting hardware 4" above and 4"-6" beyond each side of the window frame, if space allows.

REMINDER:

- Clip rings will add 2" - 4" of length to your panels.